



TO CUSTOMISE SETTINGS FOR SENDING FAX



- 1. Click Start
- 2. Go to **Programs**
- 3. Click Canon MultiPASS L60
- 4. Click MultiPASS Desktop Manager 2.61
- 5. Click **Setup**
- 6. Click the **Send Fax** tab





- 7. Enter the relevant details
- 8. Click OK

A dialog box will appear as below:



9. Click YES and the new settings and information will be downloaded to the facsimile machine.